

MX-9

# USER MANUAL

**VILTRUS**  

---

**ELECTRONICS**

# Contents

1. Introduction.....	6
Figure 1. MX-9 Configurator.....	6
2. Setting up connection to the device.....	6
Figure 2. MX-9 connection interfaces .....	6
2.1 USB connection .....	7
Figure 3. USB connection set up .....	7
2.2 ETHERNET Connection.....	7
Figure 4. Ethernet connection set up .....	8
2.3 GPRS connection.....	8
Figure 6. GPRS connection set up.....	8
2.4 MX-9 connection diagrams.....	7
Figure 7. MX-9 typical connection diagrams .....	7
3. "Start" tab .....	7
3.1 MX-9 Basic Information .....	7
Figure 8. "Start" tab. MX-9 basic information .....	8
3.2 Configuration files .....	8
Figure 9. "Start" tab. Configuration files management .....	9
3.3 Status indicators.....	9
Figure 10. "Start" tab. Status indicators .....	10
4. "Discrete inputs" tab .....	10
Figure 11. "Discrete inputs" tab.....	11
5. "Communication" tab .....	11
5.1 Communication > Ethernet.....	11
Figure 12. "Ethernet" Configuration tab.....	12
5.2 Communication > GPRS .....	12
Figure 13. "GPRS" Tab. Enabling communication .....	12
Figure 14. "GPRS" tab. Internet Service Provider access data configuration .....	13
Figure 15. "GPRS" tab. Connection status.....	14
Figure 16. "GPRS" tab. DynDNS configuration .....	14

5.3 Communication > UARTs.....	15
Figure 17. "UARTs" tab.....	15
5.4 Communication > Virtual interfaces.....	15
Figure 18. "Virtual interfaces" tab.....	16
5.5 Communication > Data transfer .....	17
Figure 19. "Data transfer" tab. CSV file structure definition.....	17
Figure 20. Setting up Datalogging period.....	18
Figure 21. "Data transfer" tab. FTP client configuration .....	19
Figure 22. "Data transfer" tab. MQTT configuration .....	20
5.6 Communication > FTP Server.....	20
Figure 23. "Communication > FTP server" tab.....	21
5.7 Communication > MQTT Subscriber .....	21
Figure 24. "Communication > MQTT Subscriber" tab. ....	22
5.8 Communication > Routing.....	22
<input type="checkbox"/> TCP/IP - serial (request).....	22
Figure 25. "Communication > Routing" tab. TCP/IP - serial (request) routing configuration .....	23
Figure 27 "Communication > Routing" tab. TCP/IP - serial (transparent) routing configuration .....	24
Figure 28. "Communication > Routing" tab. Modbus TCP/IP – Modbus RTU routing configuration .....	24
5.9 Communication > Connected devices.....	25
5.9.1 M-Bus devices.....	25
Figure 29. "M-Bus devices" tab. Communication configuration.....	25
Figure 30. MBus devices Self-discovery and steps to be followed.....	26
Figure 31. New device included in the M-bus client. ....	26
Figure 32. After delete missing .....	27
Figure 33. After finish and send .....	27
Figure 34. Updating data position .....	27
Figure 35. Click on "data/parameters" button.....	28
Figure 36. Read available parameters .....	28
Figure 37. List of available parameters .....	28
Figure 38. List of parameters indexes.....	29
Figure 39. Saving the configuration. ....	29
Figure 40. Saved configurations .....	29

Figure 41. Mbus Current values.....	30
Figure 42. All values to user archive .....	31
Figure 43. Common parameters configuration for MBus data storage.....	31
5.9.2 Wireless M-Bus devices .....	32
Figure 45. WMBus self-discovery .....	32
Figure 46. List of available parameters .....	33
Figure 47. Saved configurations .....	33
Figure 48. Mbus Current values.....	34
Figure 49. Mbus registers to archive.....	34
5.10 Communication > Modbus devices .....	36
Figure 50. "Modbus devices" tab. Modbus RTU client parameters list configuration..	36
Figure 51. "Modbus devices" tab. Modbus TCP client parameters list configuration..	37
Figure 52. "Modbus devices" tab. Current values .....	38
5.11 Communication > Modbus register grouping.....	38
Figure 53. Modbus Client Current values (Without conversion) .....	38
Figure 55. Modbus register grouping current values.....	39
Figure 56. Converted Data from Modbus register grouping .....	39
6. "Archives" tab .....	40
Figure 57. "Archives" tab. Storage frequency configuration .....	40
Figure 58. "Archives" tab. User archive configuration .....	40
Figure 59. "Archives" tab. User archive current values .....	41
7. "Limits verification" tab .....	41
Figure 60. "Limits verification" tab .....	41
8. "Alerts" tab.....	42
8.1 SMS Alerts on Limit verification.....	42
Figure 61. SMS alerts for limits configuration .....	42
8.2 Email Alerts on Limit verification .....	42
Figure 62. Email alerts for limits configuration .....	43
8.3 MQTT Alerts on Limit verification .....	43
Figure 63. MQTT alerts for limits configuration .....	44
9. "Time parameters" tab.....	44
Figure 64. "Time Parameters" tab. Set PC time .....	44
Figure 65. "Time Parameters" tab. NTP server configuration .....	44
10. Abbreviations and explanations.....	45

12. Safety instructions .....	46
13. Technical Data.....	47
13.1 Communication interfaces.....	47
13.2 Galvanic insulation .....	47
13.3 Indication.....	47
13.4 Power supply.....	48
13.5 Construction .....	48
13.6 Climate conditions .....	48
13.7 Safety parameters .....	48
13.8 Other parameters .....	48

# 1. Introduction

This Manual will show you how to configure datalogger by using the MX-9 configurator software.




Figure 1. MX-9 Configurator

## 2. Setting up connection to the device

In order to configure the controller, user must connect its PC to the device by using any of the following interfaces:

1. USB port
2. ETHERNET interface
3. Through a GPRS connection (only accessible after configuring GPRS APN, user and password inside the controller)




Figure 2. MX-9 connection interfaces

**NOTE:** Not all the models support above interfaces. Check your ordering code first.

## 2.1 USB connection

Steps to be followed:

- Connect an USB cable class B to the correspondent port
- Open MX-9 Configuration Tool
- Set up "**Connection Parameters**" frame
  - Select "ModBus RTU" option under "Connection type"
  - Configure "Bode" and "Parity" parameters; default values are: "19200" , "none"
  - Select COM port number assigned by your PC to the USB port
  - Click on "**Get all**" to establish connection with controller.




Figure 3. USB connection set up

## 2.2 ETHERNET Connection

Steps to be followed:

- Connect a RJ45 Ethernet cable to the correspondent port.
- Open MX-9 Configuration Tool
- Set up "**Connection Parameters**" frame
  - Select "ModBus TCP/IP" option under "Connection type"
  - Add controller IP address and TCP port in "Host or IP" and "Port" text boxes respectively
  - Select "Ethernet" option under "Connection through"
  - Click on "**Connect**" to establish connection with controller.




Figure 4. Ethernet connection set up

## 2.3 GPRS connection

Steps to be followed:

- Check GPRS antenna is properly connected to the device.
- Open MX-9 Configuration Tool
- Set up "**Connection Parameters**" frame
  - Select "ModBus TCP/IP" option under "Connection type"
  - Add controller IP address and TCP port in "Host or IP" and "Port" text boxes, respectively
  - Select "GPRS" option under "Connection through"
  - Click on "**Connect**" to establish connection with controller.




Figure 6. GPRS connection set up



## 2.4 MX-9 connection diagrams

In the following Figure, the most typical connection schemes of MX-9 with PC are shown. The Configuration Tool described in this document or any other Modbus complaint software can establish a communication link making use of **Modbus RTU** and/or **Modbus TCP** protocols.




Figure 7. MX-9 typical connection diagrams

## 3. "Start" tab

### 3.1 MX-9 Basic Information

Once user has established communication with MX-9, basic information such as "*User identifier*", "*Serial number*", "*Last restart*", "*Firmware version*", "*Software version*", etc. is shown in the left frame





Figure 8. "Start" tab. MX-9 basic information

### 3.2 Configuration files

This feature enables user to save and load configuration files so that programming a number of controllers with the same configuration becomes an easy process. Steps to be followed are:

1. Set up all the configuration parameters making use of MX-9 Configuration Tool.
2. Then, under "Start" tab, click on "**Save configuration**" button. A dialog will be shown requesting user to select folder destination.
3. Once the file has been stored, connect a new controller to the PC and then click on "**Open configuration**" and select the file previously stored.
4. Then, click on "**Write configuration**" button to load such configuration into the new controller.
5. A restart will be needed so that controller can start using the loaded configuration.
6. Repeat from step 3 with all the controllers that need the same configuration.



**Figure 9. “Start” tab. Configuration files management**

### 3.3 Status indicators

Several status indicators are shown in the MX-9 configuration tool in order to inform user about current performance of Modbus communication:

7. Req: number of Modbus requests performed.
8. Answ: Number of Modbus answers received.
9. Tout: number of Modbus requests not answered (time outs raised).
10. Except: number of Modbus errors.




Figure 10. "Start" tab. Status indicators

## 4. "Discrete inputs" tab

Discrete inputs can be configured within this tab. They are shown organized in columns and configuration parameters are shown in rows as follows:

- "Current State": Graphical representation of current status (open/closed).
- "Impulse quantity": Number of pulses counted from last reset.
- "Value": Calculated from multiplying number of pulses counted (Impulse quantity) and user-defined multiplier (Impulse multiplier).
- "Enabled": user enable/disable discrete inputs to be used. In order to save memory, it is recommend to only enable inputs in use.
- "Mode":
- "Discrete Input": input works as a standard discrete input detecting its current state (1 / 0)
- "Impulse counter": input is used as a standard pulse counter, storing the amount of pulses raised.
- "Alarm signal": input is used as an alarm input.
- "Alarm state": If "Alarm signal" option is selected, controller will raised an alarm when one of the following state is reached: "Open", "Close", "Both cases".
- "Enable archiving": If enabled, events produced by discrete inputs are stored in the datalogging archive.
- "Debounce time": only pulses received within one or more "Debounce time" intervals are registered.
- "Impulse multiplier": user-defined multiplier. Values can be set from 1 to 1000. "Set initial amount of pulses": initial value for pulse counter can be set here.

NOTE: After configuration is completed, click on "**Set**" button in order to save changes.

	Chan. 1	Chan. 2	Chan. 3	Chan. 4	Chan. 5	Chan. 6	Chan. 7	Chan. 8
Current state								
Impulse quantity	15	0	0	0	0	0		
Value	15,000	0,000	0,000	0,000	0,000	0,000		
Enabled	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Mode	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal	<input type="radio"/> Discrete. inp. <input checked="" type="radio"/> Impulse count <input type="radio"/> Alarm signal
Alarm state	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases
Enable archiving	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
State to archive	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases	<input checked="" type="radio"/> Open <input type="radio"/> Close <input type="radio"/> Both cases
Debounce time (ms)	50	50	50	50	257	257	257	257
Impulse multiplier	1,0000	1,0000	1,0000	1,0000	1,0000	1,0000	1,0000	1,0000
<div>Set</div> <div>Get</div>								

	Chan. 1	Chan. 2	Chan. 3	Chan. 4	Chan. 5	Chan. 6
Set the initial amount of impulses						
Impulse quantity						
	<div>Set</div>	<div>Set</div>	<div>Set</div>	<div>Set</div>	<div>Set</div>	<div>Set</div>
<div>Clear</div>						

Req: 368    Answer: 337    TOut: 7    Except: 25

Figure 11. "Discrete inputs" tab

## 5. "Communication" tab

### 5.1 Communication > Ethernet

Ethernet interface parameters can be configured within this tab:

- "MAC number": Media Access Control address
- "IP address"
- "Gateway IP"
- "Mask"

NOTE: After configuration is completed, click on "**Set**" button in order to save changes.

Figure 12. "Ethernet" Configuration tab

## 5.2 Communication > GPRS

As previously described, MX-9 can be configured through a GPRS link. In order to do so, user must enable GPRS connection as shown below. Then, click on **"Set"** button in order to save changes.

Figure 13. "GPRS" Tab. Enabling communication

Within this tab, different services can be configured or checked.

1. GPRS connection parameters:

- "APN": access point name provided by Internet Service Provider (ISP).

If needed by ISP, credentials can also be configured here:

- "Username": provided by ISP.
- "Password": provided by ISP.

NOTE: After configuration is completed, click on "**Set**" button in order to save changes.

Discrete inputs | Communication | Archives | Alerts | Time parameters | Start

Ethernet | **GPRS** | UARTs | Virtual interfaces | Routing | Connected devices | Modbus devices | Modbus register grouping

Enabled ☒ GPRS-GSM mode  
☒ GPRS ☐ GPRS-GSM  
☐ GSM ☐ GPRS transpar.

Signal level measurement  
☐ After restart ☒ Periodically

Signal level [Set] [Get]

**GPRS** | DDNS setting

APN: ac.vodafone.es

Number of connection failures before restart: 20

Time before restart if no packets received: 7200 sec.

Incoming IP filter  
Filter enabled: ☐

IP 1	255	255	255	255
IP 2	255	255	255	255
IP 3	255	255	255	255
IP 4	255	255	255	255
IP 5	255	255	255	255


GPRS login  
Enabled ☒  
User name: VODAFONE  
Password: VODAFONE  
[Set] [Get]

[Set] [Get]


Req: 166 | Answ: 157 | TOut: 0 | Except: 9

**Figure 14. "GPRS" tab. Internet Service Provider access data configuration**

2. Connection status. Once GPRS connection is established, status will be shown as below:



3. DynDNS account configuration: in order to avoid the need to have a fixed IP address to be able to remotely access the device, it is possible to set up a DynDNS account under the "DDNS setting". Steps to be followed are:
  - Select "Enable"
  - Fill in information according to your DynDNS account
  - Click on "Load from file" and select "dyndns.org\_Register\_String.txt" which contains the connection string to be sent to DynDNS servers.



NOTE: After configuration is completed, click on "Set" button in order to save changes. NOTE: It is recommended to disable GPRS connection if not used.



### 5.3 Communication > UARTs

Each UART can be configured individually. It is recommended to check peripheral devices UART constraints before setting up parameters in the controller configuration tool.

NOTE: All devices connected to the same MX-9 UART must have the same communication parameters.

- "Bode": Transmission rate (bauds per second).
- "Parity": Communication Parity.
- "Data bits": Number of data bits within the communication packet.
- "Stop bits": Number of stop bits within the communication packet.
- "Packetization":
  - "Time": One packet time has been reached, it is considered that the packet has been properly sent.
  - "Symbol". Every time a "packet symbol" is received, it is considered that the packet has been properly sent.
  - "Length". Once the "packet byte count" has been reached, it is considered that the packet has been properly sent.
- "Packet time": Transmission duration.
- "Packet symbol": Symbol which defines packet ending.
- "Packet byte count": Length which defines packet size
- "Mode": Full duplex or half duplex
- "Destination of DTR": bit which defines the "Data ready" state has been reached. It must be configured following peripheral devices connected to MX-9 UARTs vendor information. By default, if this information is not available, it is recommended to select "OFF when send" option.

NOTE: After configuration is completed, click on "Set" button in order to save changes.

	UART 1	UART 2	UART 3	UART 4
Bode	300 600 1200 2400 4800 9600 19200 38400	300 600 1200 2400 4800 9600 19200 38400	300 600 1200 2400 4800 9600 19200 38400	300 600 1200 2400 4800 9600 19200 38400
Parity	Even Odd Mark Space None	Even Odd Mark Space None	Even Odd Mark Space None	Even Odd Mark Space None
Data bits	5 6 7 8	5 6 7 8	5 6 7 8	5 6 7 8
Stop bits	1 1.5 2	1 1.5 2	1 1.5 2	1 1.5 2
Packetization	Time Symbol Length	Time Symbol Length	Time Symbol Length	Time Symbol Length
Packet time (msec)	100	100	100	100
Packet symbol (Hex)	0D	FF	0D	FF
Packet byte count	65535	65535	65535	65535
Mode	Full duplex Half duplex	Full duplex Half duplex	Full duplex Half duplex	Full duplex Half duplex
Destination of DTR	Always OFF Always ON OFF when send ON when send	Always OFF Always ON OFF when send ON when send	Always OFF Always ON OFF when send ON when send	Always OFF Always ON OFF when send ON when send

Figure 17. "UARTs" tab

### 5.4 Communication > Virtual interfaces

The MX-9 can perform as communication gateway Modbus server/client and datalogger simultaneously. In order to set up these options, different virtual interfaces are needed as shown below

Discrete inputs Communication Archives Alerts Time parameters Start

Ethernet GPRS UARTs Virtual interfaces Routing Connected devices Modbus devices Modbus register grouping

**COM Client**

	COM 1	COM 2	COM 3	COM 4	COM 5	COM 6
Enabled	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
UART	UART 3	UART 1	UART 1	UART 1	UART 1	UART 1
Stack depth	2	1	1	1	1	1
Timeout	65535	65535	65535	65535	65535	65535
Number of	4	2	2	2	2	2

Set Get

**Modbus RTU Client**

	1	2
Enabled	<input checked="" type="checkbox"/>	<input type="checkbox"/>
UART	UART 3	UART 1
Stack depth	1	1
Timeout (msec.)	1000	1000
Number of repeats	2	2
Delay before next req. (msec.)	100	100

Set Get

**Modbus RTU Server**

	1	2
Enabled	<input type="checkbox"/>	<input type="checkbox"/>
UART	UART 1	UART 1
Address	255	255

Set Get

Req: 166 Answ: 157 TOut: 0 Except: 9

**Figure 18. "Virtual interfaces" tab**

- **"COM Client"**. It is needed to configure a COM Client every time a "transparent" communication mode or M-Bus compatibility is needed. This is mandatory in order to read devices not compatible with Modbus RTU/TCP protocols. Configuration parameters are:
  - "Enable": Do not enable any COM client if not needed.
  - "UART": Select the UART number in which a COM Client will be configured. NOTE: Once a given UART is selected to be a COM client, it cannot be used with any other configuration such as Modbus client/server.
  - "Stack depth": number of parallel executions that can be done in parallel by the COM client.
  - "Timeout": it defines the amount of milliseconds defined as time out.
  - "Number of repeats": number of retries defined in case of transmission error. NOTE: COM Client must always be used when peripheral devices connected to a given UART use protocols such as M-Bus, IEC-102, DLMS, etc. NOTE: After configuration is completed, click on "Set" button in order to save changes.
- **"Modbus RTU Client"**. This mode working mode must be used when the MX-9 behaves as master in a Modbus RTU network (it sends Modbus requests to the slaves connected to the Modbus RTU network). These requests will be defined under the "Modbus devices" tab. Parameters to be configured are:
  - "Enable": Do not enable any Modbus RTU client if not needed.
  - "UART": Select the UART to be associated to the Modbus RTU client. NOTE: Once a given UART is selected to be a Modbus RTU client, it cannot be used with any other configuration such as COM client.
  - "Stack depth": number of requests that can be stacked in the UART buffer. It is recommended to set this value to 1 by default.
  - "Timeout": it defines the amount of milliseconds defined as time out.
  - "Number of repeats": number of retries defined in case of transmission error.

- "Delay before next request": In case peripheral devices need some "extra time" to answer after a received request

NOTE: After configuration is completed, click on "**Set**" button in order to save changes.

- "Modbus RTU Server". This mode is used when the MX-9 will be used as Modbus slave in a network. Requests from a Modbus server will be received and answered.
- "Enable": Do not enable any Modbus RTU server if not needed.
- "UART": Select the UART to be associated to the Modbus RTU server.

NOTE: Once a given UART is selected to be a Modbus RTU server, it cannot be used with any other configuration such as COM client.

- "Address": Define Modbus address for MX-9. Modbus master must send requests to the given address.

NOTE: After configuration is completed, click on "**Set**" button in order to save changes.

## 5.5 Communication > Data transfer

Data collected by MX-9 can be sent in two different ways: FTP and MQTT protocols. In both cases, parameters to be sent must be configured by setting up the data structure following the next steps:

- Go to *Communication>Data transfer>Common parameters>* and configure the following parameters:
- "Amount of group of registers": Number of registers or group of registers to be stored in the CSV file.
- "Set user archive". If selected, it enables automatic storage of selected registers in the internal memory. It is recommended to always select this option so that in case of file transmission failure, data can be retrieved and resent when communication is reestablished.
- "Parameter". It is filled in automatically.
- "Register/Coil" Initial Modbus register address.
- "Amount of registers". Number of registers to be stored from the initial Modbus registers address.
- "Format": Data type of registered parameter.
- "Header": Fixed column header to be written in CSV file.
- "Dimension": Extra column in which data units can be stored.

Amount of groups of registers: 3

Set user archive: ☒

Parameter	Register/Coil	Amount of registers	Format	Header	Dimension
1	52000	2	Float	Iluminacion Sala 1	Lux
2	52002	2	unsigned long	VAC Contador Sala 1	V
3	52002	2	unsigned long	AP Contador Sala 1	W

Set Get

Req: 152, Answer: 148, TDu: 0, Except: 4

Figure 19. "Data transfer" tab. CSV file structure definition

NOTE: Go to *Archives>Configuration* and specify 'User archive (min)' value to set the datalogging period as shown in the following figure.

The screenshot shows a software interface for configuring archives. At the top, there are tabs: 'Communication', 'Archives', 'Parameters', and 'Start'. The 'Archives' tab is active, and within it, the 'Configuration' sub-tab is selected. Below the tabs, there are two main sections: 'Storage parameters' and 'Records in archives'.

**Storage parameters:**

	Period	Delay
Heat account (min.)	60	0
Gas account (min.)	60	0
Water account (min.)	60	0
Electricity account (min.)	60	0
<b>User archive (min.)</b>	<b>5</b>	<b>0</b>

**Records in archives:**

	Records	
Heat account	24	Clear
Gas account	24	Clear
Water account	24	Clear
Electricity account	24	Clear
User archive	0	Clear

At the bottom of the 'Storage parameters' section, there are two buttons: 'Set' and 'Get'. A red arrow points to the 'Set' button. The 'User archive (min.)' row in the 'Storage parameters' table is highlighted with a red box, and a red arrow points to the '5' in the 'Period' column.

**Figure 20. Setting up Datalogging period**

NOTE: After configuration is completed, click on "Set" button in order to save changes.

After configuring data structure, user can select in which way the device will send data. It can be sent in a csv file to a remote FTP server or in a JSON formatted message to an MQTT Broker.

1. Configure FTP client: Go to *Communication>Data transfer>FTP>* and configure the following parameters:

- "FTP server": Up to 4 different FTP connections to remote FTP servers can be configured.
- "Enabled": Select it to enable an FTP connection
- "FTP Port": By default, 21 but can be changed.
- "Transfer period": It defines interval between CSV file sending tasks.
- "Number of last records to be read": It defines maximum number of previous data stored and not sent due to communication error. These data will be sent in a CSV file when communication is restored.
- "Transmission channel": It can be Ethernet or GPRS
- "URL and directory of FTP servers": It defines the complete FTP server URL where CSV file will be hosted.
- Username and password of FTP server: to be configured in case credentials are requested by FTP server.

	FTP server 1	FTP server 2	FTP server 3	FTP server 4
Enabled	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
FTP port	21	21	21	21
Transfer period (min.)	10	2	15	10
Repeat transfer if failure (min.)	5	1	5	5
Max number of last records to be sent	10	1	10	10
Transmission channel	<input type="radio"/> Ethernet <input checked="" type="radio"/> GPRS	<input type="radio"/> Ethernet <input checked="" type="radio"/> GPRS	<input type="radio"/> Ethernet <input checked="" type="radio"/> GPRS	<input type="radio"/> Ethernet <input checked="" type="radio"/> GPRS

Name template of the file to be sent: YYYY\_MM\_DD\_HH\_NN.csv

FTP server	URL and directory
1	192.168.1.1/
2	
3	
4	

FTP server	User name
1	user1
2	
3	
4	

FTP server	Password
1	pass1
2	
3	
4	

FTP server	Status	Successful/attemp/last record transfer times
1	File transmitted	09/08/2016 12:13:19 09/08/2016 12:13:02 09/08/2016 12:13:00
2	Not active	01/01/1998 00:00:00 01/01/1998 00:00:00 03/08/2016 10:08:00
3	Not active	01/01/1998 00:00:00 01/01/1998 00:00:00 26/07/2016 12:48:00
4	Not active	01/01/1998 00:00:00 01/01/1998 00:00:00 01/01/1998 00:00:00

Req: 805    Answer: 801    TOut: 0    Except: 4

**Figure 21. "Data transfer" tab. FTP client configuration**

NOTE: In order to synchronize user archive storage and csv sending file through FTP link, the following constraints must be taken into account:

"User archive sample time" must be equal or below the FTP "transfer period"

FTP "Repeat transfer if failure" time is recommended to be about half time of FTP "transfer period".

2. Configure MQTT publisher: Go to *Communication>Data transfer>MQTT>* and configure the following parameters:

- "Topic": A topic is a UTF-8 string, which is used by the broker to filter messages for each connected client. A topic consists of one or more topic levels. Each topic level is separated by a forward slash (topic level separator). Example: "building1/zoneA/room2"
- "What type of data to be transferred": It defines the functionality the device will have with regard to MQTT data sending:
- "Disabled": if selected, the device will not send anything through MQTT port.
- "Current values": MX-9 will send real time values of parameters configured in Common Parameters tab. In this case, sampling/sending period can be set from 1 to 86400 seconds.
- "User Archive records": this feature sends data every datalogging period set in *Archives>Configuration>'User archive (min)'* value.

NOTE: After configuration is completed, click on "Set" button in order to save changes and "RESTART" (start menu>restart).


**Figure 22. “Data transfer” tab. MQTT configuration**

Once properly configured both this tab and *Communication>MQTT Subscriber* one, JSON formatted messages will be sent to the MQTT Broker (for example, RabbitMQ) In the following example, a “user archive records” message with a discrete input status is sent:

```
{
  "SN": "86004",
  "name": "MX-9",
  "header": {
    "startTime": "2016-02-07T15:06:00.000Z",
    "endTime": "2016-02-07T15:06:00.000Z",
    "recordCount": 2,
    "columns": {
      "0": {
        "id": "0",
        "name": "relay1",
        "dataType": "NUMBER",
        "format": "unsigned short"
      }
    },
    "data": [
      {
        "ts": "2016-02-07T15:06:00.000Z",
        "f": {
          "0": { "v": 0 }
        }
      }
    ]
  }
}
```

## 5.6 Communication > FTP Server


If the MX-9 has a micro SD card installed, it can act as FTP server. In this tab, user can configure both user and password to be used as credentials to enter into the internal file system through an FTP connection.



**Figure 23. “Communication > FTP server” tab.**

Once properly configured, user can access the internal file system making use of any FTP client (such as Filezilla).

The file system structure is as follows:



In the root, a "CURRENT\_DATA.csv" file is stored. You will find all the data generated by the MX-9 configured in "Communication > Data Transfer > Common parameters" tab and not yet sent to the remote FTP server.

Moreover, under “Storage” folder, files for each of the archives set in the “Archives” tab can be found. They are created on a daily basis.

Nombre de archivo	Tamaño de archivo	Última modificación	Permisos	Propietario...
..				
2016_07_29ud.csv	2.890	29/07/2016	-rw-r--r--	mpc mpc
2016_08_01ud.csv	119.023	01/08/2016	-rw-r--r--	mpc mpc
2016_08_02ud.csv	114.908	02/08/2016	-rw-r--r--	mpc mpc
2016_08_03ud.csv	36.858	03/08/2016	-rw-r--r--	mpc mpc
2016_08_05ud.csv	21.896	05/08/2016	-rw-r--r--	mpc mpc
2016_08_08ud.csv	196.026	08/08/2016	-rw-r--r--	mpc mpc
2016_08_09ud.csv	233.450	09/08/2016	-rw-r--r--	mpc mpc

## 5.7 Communication > MQTT Subscriber

If the MX-9 supports MQTT protocol, within this tab, user will need to configure MQTT Broker (remote server towards data will be sent). it can act as FTP server. In this tab, user can configure both user and password to be used as credentials to enter into the internal file system through an FTP connection.



**Figure 24. “Communication > MQTT Subscriber” tab.**

This protocol needs to have a central server that will collect all the data sent by the MX-9. Thus, first of all, user must enable this mode. In addition, the following parameters must be configured: ○ "MQTT Broker URL": This is the server URL where data will be sent to

- "MQTT Broker Port": By default, MQTT protocol is 1883 but it can be change in this box.
- "Subscriber identifier": This is the device identifier.
- "User name": Broker user with credentials to publish messages.
- "User password": Broker password.
- "Session keep alive": number of seconds the session is kept alive after message has been sent. By default, 60 seconds.

NOTE: After configuration is completed, click on **"Set"** button in order to save changes.

## 5.8 Communication > Routing

Since MX-9 can work as a communication gateway, several routing modes can be implemented in it. When used as gateway, all the information received by MX-9 is forwarded following the chosen configuration, not storing any of these data in its memory:

- **TCP/IP - serial (request)**

Making use of this mode, two devices can be connected between a TCP/IP port and a UART. In this case, the TCP/IP device must initiate communication and the RS485/RS232 will answer under "request".

Parameters to be configured are:

- "Enabled": Mode enabling/disabling.
- "Socket live time": Duration in which socket is kept active. When the device initiating communication sends a request command to the slave device, communication will be shut down when this time is reached.
- Routing 1,2,3,4,5,6:
- "TCP port": Routing is done through this port.
- "COM client": Previously configured under "Communication > Virtual interfaces" tab

NOTE: After configuration is completed, click on **"Set"** button in order to save changes.







Figure 25. "Communication > Routing" tab. TCP/IP - serial (request) routing configuration

- **TCP/IP - serial (transparent)**

Making use of this mode, two or more devices can be connected between a TCP/IP port and a UART. In this case, any device can initiate communication. The MX-9 manages several communications seamlessly. Parameters to be configured are:

- Routing 1,2,3,4,5,6:
- "Enabled": Mode enabling/disabling.
- "TCP port": Routing is done through this port.
- "UART": Previously configured under "Communication > UARTs" tab.
- "Stack depth": Number of concurrent transmissions.
- "Connections count": Number of devices to be connected.
- "Socket live time": Duration in which socket is kept active. When the device initiating communication sends a request command to the slave device, communication will be shut down when this time is reached.

NOTE: After configuration is completed, click on "Set" button in order to save changes.



**Figure 27 “Communication > Routing” tab. TCP/IP - serial (transparent) routing configuration**


- **Modbus TCP/IP - ModBus RTU**

The MX-9 can also forward Modbus packets from a TCP port to an Modbus RTU client. In order to do so, Modbus TCP/IP server mode must be always enabled as shown in the figure. Also "Socket live time" parameter must be configured given that it is the duration in which socket is kept active. When the device initiating communication sends a request command to the slave device, communication will be shut down when this time is reached.

This routing mode can be done in two ways:

- Destination "TCP port": This mode enables assignment of a TCP port to each Modbus RTU device as previously configured under *Communication>Virtual interfaces>Modbus RTU Client* tab.
- Destination "Modbus address": Within this mode, user can identify Modbus addresses to each Modbus RTU device as previously configured under *Communication>Virtual interfaces>Modbus RTU Client* tab. With this configuration, Modbus commands can be sent to devices within the network making use of the specific device Modbus address and the MX-9 IP address and TCP port 502.

NOTE: After configuration is completed, click on "Set" button in order to save changes.



**Figure 28. “Communication > Routing” tab. Modbus TCP/IP – Modbus RTU routing configuration**

## 5.9 Communication > Connected devices

Within this section, both M-Bus and Wireless M-Bus communication can be configured given that MX-9 is able to collect data from up to 8 M-Bus and up to 50 Wireless M-Bus devices.

In the following pages, a detailed description of each M-Bus and Wireless M-Bus meter configuration step is done.

### 5.9.1 M-Bus devices

Steps to be followed are:

- Enable COM Client under *Communication>Virtual interfaces>COM Client* tab.
- Go to *Communication > Connected devices > Mbus devices > Configuration* and configure the following parameters:
- "Enabled": Select which MBus interface will be active.
- "COM Client": Select COM Client previously configured.
- "Amount of meters": Configure the number of M-Bus devices to be read.
- "Read Period": Reading interval in minutes.





Figure 29. "M-Bus devices" tab. Communication configuration

NOTE: After configuration is completed, click on "Set" button in order to save changes. Also, perform a hardware reset.

- Once MX-9 has been restarted, go to *Communication>Connected devices>Mbus devices>Configuration* and click on "Search devices in 1st line" button.

After a few seconds, a list including all the M-Bus devices connected to the network will appear:



**Figure 30. Mbus devices Self-discovery and steps to be followed.**

Once a new device is discovered, it must be added to the Mbus client, the following steps must be followed:


- Click on "Include newly found"
- Click on "delete missing" if you want to delete old meters which are not needed.
- Click on "Finish and send"

If several new devices are discovered, the following steps should be done:

- Click on "Merge all"
- Click on "Finish and send"

All devices online appear in green and the ones offline in red. An step-by-step guide is shown in the following figures: \_

#### STEP 1: Including new devices



**Figure 31. New device included in the M-bus client.**

#### STEP 2: Delete missing devices




Figure 32. After delete missing

### STEP 3: Finish and send




Figure 33. After finish and send

Once the new device is added to the M-bus client, it is recommended to modify the data position count in order to optimize the internal memory of the controller (from 2 to 1 in the example above). Once updated, click on "SET":




Figure 34. Updating data position

Once the M-bus client is configured, it is possible to read data available in the meter:




Figure 35. Click on "data/parameters" button

STEP 4: Click on "Read available parameters"




Figure 36. Read available parameters

A list of parameters will be shown. User must select which parameters provided by the M-Bus devices should be stored in the internal MX-9 memory.




Figure 37. List of available parameters

STEP 5: Select M-Bus meter parameters to be stored



Each selected parameter must be configured with an ordering index according to the data format that the meter presents in its datasheet. This index will order the stored data in the internal memory map.

The screenshot shows a window titled 'Time parameters' with a tabbed interface. The 'Parameters in device' tab is active, displaying a table of parameters and their storage configurations. The 'Selected parameters' tab is also visible, showing the same parameters with additional indexing information.

Pos No	Parameter	Storage number	Tariff	SubUnit	Type of parameter
1	Identification Nr.	1	1	1	Instantaneous
2	Manufacturer, Medium	1	1	1	Instantaneous
3	Fabrication No	1	1	1	Instantaneous
4	Energy(Wh)	1	1	1	Instantaneous
5	Volume(m3)	1	1	1	Instantaneous
6	On Time(hours)	1	1	1	Instantaneous
7	Flow Temperature(C)	1	1	1	Instantaneous
8	Return Temperature(C)	1	1	1	Instantaneous
9	Temperature Difference(K)	1	1	1	Instantaneous
10	Power(W)	1	1	1	Instantaneous
11	Power(W)	1	1	1	Maximum value
12	Volume Flow(m3/h)	1	1	1	Instantaneous
13	Volume Flow(m3/h)	1	1	1	Maximum value
14	Energy(Wh)	1	2	1	Instantaneous
15	Energy(Wh)	1	3	1	Instantaneous
16	Volume(m3)	1	1	2	Instantaneous
17	Volume(m3)	1	1	3	Instantaneous

Figure 38. List of parameters indexes.

After indexing parameters, it is needed to save the configuration. Click on "Save As" and give it a name so that user can reuse this configuration for similar meters in the future

The screenshot shows the same 'Time parameters' window as Figure 38, but with a 'Save As' dialog box open. The dialog box prompts the user to enter a name for the configuration, with 'MULTICAL 602' entered in the text field. The 'OK' button is highlighted.

Figure 39. Saving the configuration.

Once the configuration is saved, it appears in the "Type" list. By clicking over the list you can select the current online configurations. After making the selection, click on SET:

The screenshot shows a window titled 'Saved configurations' with a tabbed interface. The 'Configuration' tab is active, displaying a table of saved configurations. The 'Type' column is highlighted, and a red arrow points to the 'MULTICAL 602' entry. The 'Set' button is also highlighted.

Type	Addressing mode	Address	Data position	Device number	Manufacturer	Medium
1	Prim	4 Secs, 6964540520203F8D	2	69645406	K/M	Water Mode 2

Figure 40. Saved configurations

## STEP 6: Check current values

Device/Parameter	Last read time	Storage number	Tariff	SubUnit	Type of parameter	Double float	Double long	Float	Long
2-BUSICAL 002499645490	28022017 18:08:40								
Identification Nr		1	1	1	Instantaneous				
Manufacture, Medium, Chassis		1	1	1	Instantaneous				
Position No		1	1	1	Instantaneous				
Energy(Wh)		1	1	1	Instantaneous			55426008.800	
Volume(m3)		1	1	1	Instantaneous			28547.800	
On Time(hours)		1	1	1	Instantaneous				
Flow Temperature(C)		1	1	1	Instantaneous			28.570	
Return Temperature(C)		1	1	1	Instantaneous			27.100	
Temperature Difference(C)		1	1	1	Instantaneous			0.500	
Flow(m3)		1	1	1	Instantaneous				
Power(W)		1	1	1	Maximum				
Volume Flow(m3/h)		1	1	1	Instantaneous				
Volume Flow(m3/d)		1	1	1	Maximum				
Energy(Wh)		1	2	1	Instantaneous			0.000	
Flow(m3/h)		1	3	1	Instantaneous				
Volume(m3)		1	1	2	Instantaneous				
Volume(m3)		1	1	3	Instantaneous				
Flow(m3/h)		1	1	4	Instantaneous				

Figure 41. Mbus Current values

## STEP 7: Configuring data logging

These data will be included into its corresponding MX-9 Modbus register. The MX-9 has a Modbus array structure to store M-Bus parameters. Thus, in order to collect specific parameters, user must select them by numbering within the array as shown in previous steps. There are different arrays for different data format as shown in the following table:

Registers	Mbus meters data (1...50)	Data format	R/W
	1-st Mbus counter's data		
24000	Status (0-not read, 0xffffread)	Int16	R
24001-24002	Reading time (UNIX time)	Int32	R
24003-24082	Double data[20]	F64	R
24083-24098	Long data[4]	Int64	R
24099-24158	Float data[30]	F32	R
24159-24178	Int data[10]	Int32	R
	2-nd Mbus counter's data		
24179-24357	...		R
	50-th Mbus counter's data		
32771-32949	...		R

In the previous example, we have given float index “1” to “Energy(Wh)” parameter. Thus, we will find it in Modbus register 24099 while “Fabrication number” has been given double float index “1” being stored in Modbus register 24003.

This configuration can be saved by clicking on the “Save as” button.

It is possible to send these data automatically to the user archive memory (for datalogging) by clicking on “All values to archive”






Figure 42. All values to user archive

NOTE: If there are some registers configured previously in "common parameters" to be stored in the user archive they will be deleted by using this function. In case of using user archive memory it is recommended to configure first the Mbus client module.

After click in "All values to archive" all selected parameters will be automatically configured in "Common parameters" list, which will be stored in "User archive". In order to update changes, click in "SET" button".




Figure 43. Common parameters configuration for Mbus data storage

Communication	Archives	Limits verification	Alerts	Time parameters	Start
Configuration	User archive configuration	Values			
Heat	Events	User archive	Diagnostics		

Time	Energy(Wh)	Volume(m3)	Flow Temperature(C)	Return Temperature(C)	Temperature Difference(K)	Energy(Wh)
28/02/2017 18:14:00	55420000.0000	20547.0000	23.9900	23.5200	0.4700	0.0000
28/02/2017 18:13:00	55420000.0000	20547.0000	23.9900	23.5200	0.4700	0.0000
28/02/2017 18:12:00	55420000.0000	20547.0000	24.2400	23.8500	0.3900	0.0000
28/02/2017 18:11:00	55420000.0000	20547.0000	24.3900	24.0800	0.3100	0.0000

Figure 44. Mbus parameters in user archive module

## 5.9.2 Wireless M-Bus devices

The MX-9 automatically detects standard Wireless M-Bus devices. In the following pages, a detailed description of each configuration step is done:

- Go to *Communication > Connected devices > WMBUS > Configuration* and click on "Refresh" to scan wireless spectrum.
- Click on "+" to add each meter to the "Selected WMBus devices" list in the right side frame.
- If your meter data is encrypted, enter decryption key and click on "Set".
- Click on right button and select "Read available parameters".

Communication	Archives	Time parameters	Start
Ethernet	GPFS	UARTs	Virtual interfaces
Data transfer	FTP server	Routing	Connected devices
Modbus devices	Modbus register grouping		

Heat meters	MBus devices	WMBUS
-------------	--------------	-------

Configuration					
"Visible" WMBus devices					
Pos No	Scan time	Identifier	Receiv. packet count	Manufacturer	Signal level
1	19/12/2016 12:04:51	69713177	4	KAM	189

Selected WMBus devices				
Pos No	Type	Identifier	Data position	Decryption key (Hex)
1	Unknown	69713177	1	414C36060272F716448EA5266D

View/Edit list of parameters  
Read available parameters

Set Get

Clear Refresh

Figure 45. WMBus self-discovery

A list of parameters will be shown. User must select which parameters provided by the WM-Bus devices should be stored in the internal MX-9 memory. Each selected parameter must be configured with an ordering index according to the data format that the meter presents in its datasheet. This index will order the stored data in the internal memory map.

After indexing parameters, it is needed to save the configuration. Click on "Save As" and give it a name so that user can reuse this configuration for similar meters in the future

Unknown Device number 69713177

Parameters in device						Selected parameters									
Pos No	Parameter	Storage number	Tariff	SubUnit	Type of parameter	Pos No	Parameter	Storage number	Tariff	SubUnit	Type of parameter	Double float index	Double long index	Float index	Long index
1	FE 00	1	1	1	Instantaneous	1	FE 00	1	1	1	Instantaneous				1
2	FE 01	1	1	1	Instantaneous	2	FE 01	1	1	1	Instantaneous				2
3	F9 FF 15	1	1	1	Instantaneous	3	F9 FF 15	1	1	1	Instantaneous				3
4	Energy(Wh)	1	1	1	Instantaneous	4	Energy(Wh)	1	1	1	Instantaneous			1	
5	EE FF 07	1	1	1	Instantaneous	5	EE FF 07	1	1	1	Instantaneous				
6	EE FF 08	1	1	1	Instantaneous	6	EE FF 08	1	1	1	Instantaneous				
7	Volume(m3)	1	1	1	Instantaneous	7	Volume(m3)	1	1	1	Instantaneous			2	
8	Volume(m3)	1	1	2	Instantaneous	8	Volume(m3)	1	1	2	Instantaneous			3	
9	Volume(m3)	1	1	3	Instantaneous	9	Volume(m3)	1	1	3	Instantaneous			4	
10	FD 17	1	1	1	Instantaneous	10	Volume(m3)	1	1	3	Instantaneous			5	
11	Time Point	1	1	1	Instantaneous	11	Volume(m3)	1	1	3	Instantaneous			6	
12	Time Point	2	1	1	Instantaneous	12	Volume(m3)	1	1	3	Instantaneous				
13	Energy(Wh)	2	1	1	Instantaneous	13	Volume(m3)	1	1	3	Instantaneous				
14	Volume(m3)	2	1	1	Instantaneous	14	Volume(m3)	1	1	3	Instantaneous				
15	Volume(m3)	2	1	2	Instantaneous	15	Volume(m3)	1	1	3	Instantaneous				
16	Volume(m3)	2	1	3	Instantaneous	16	Volume(m3)	2	1	3	Instantaneous				
17	Volume Flow(m3/h)	1	1	1	Instantaneous	17	Volume Flow(m3/h)	1	1	1	Instantaneous				

New type of Mbus device

Name: KAM

OK Cancel

Select all Save As Close

**Figure 46. List of available parameters**

Once the configuration is saved, it appears in the "Type" list. By clicking over the list you can select the current online configurations. After making the selection, click on SET:

Communication Archives Time parameters Start

Ethernet GPRS UARTs Virtual interfaces Data transfer FTP server Routing Connected devices Modbus devices Modbus register grouping

Heat meters Mbus devices WMBUS

Configuration

Pos No	Scan time	Identifier	Receiv packet count	Manufact urer	Signal level
1	19/12/2016 12:04:51	69713177	4	KAM	189

Selected WMBus devices

Pos No	Type	Identifier	Data position	Decryption key (Hex)
1	Unknown	69713177	1	414C36060272F716448EA526D7C5276

Unknown MC-4 PKE Weser Zenner KAM

Set Get

Clear Refresh

**Figure 47. Saved configurations**

Next step is to check current values by going to *Communication* > *Connected devices* > *Mbus devices* > *Current values*

Communication

Archives

Time parameters

Start

Ethernet

GPFS

UARTs

Virtual interfaces

Data transfer

FTP server

Routing

Connected devices

Modbus devices

Modbus register grouping

Heat meters

MBus devices

WMBUS

Configuration

Current values

Device/Parameter	Last read time	Storage number	Tariff	SubUnit	Type of parameter	Double float	Double long	Float	Long
1 - KAM (69713177)	19/12/2016 12:13:17								
FE 00		1	1	1	Instantaneou				69713177
FE 01		1	1	1	Instantaneou				757859328
F9 FF 15		1	1	1	Instantaneou				4881
Energy(Wh)		1	1	1	Instantaneou			1844690048.0	
EE FF 07		1	1	1	Instantaneou				
EE FF 08		1	1	1	Instantaneou				
Volume(m3)		1	1	1	Instantaneou			21786.699	
Volume(m3)		1	1	2	Instantaneou			21	0.000
Volume(m3)		1	1	3	Instantaneou				0.000
FD 17		1	1	1	Instantaneou				
Time Point		1	1	1	Instantaneou			1482105600.0	
Time Point		2	1	1	Instantaneou			1469923200.0	
Energy(Wh)		2	1	1	Instantaneou				
Volume(m3)		2	1	1	Instantaneou				
Volume(m3)		2	1	2	Instantaneou				
Volume(m3)		2	1	3	Instantaneou				
Volume Flow(m3/h)		1	1	1	Instantaneou			24.720	
Flow Temperature(C )		1	1	1	Instantaneou				
Return Temperature(C )		1	1	1	Instantaneou				

Figure 48. Mbus Current values

After click in "All values to archive" all selected parameters will be automatically configured in "Common parameters" list, which will be stored in "User archive". To update changes, click in "SET" button".

All values to archive

Req: 1239    Answ: 1238    TOut: 0    Except: 1

Figure 49. Mbus registers to archive

Moreover, these data will be included into its corresponding MX-9 Modbus register. As in MX series, the MX-9 has a Modbus array structure to store M- Bus parameters. Thus, in order to collect specific parameters, user must select them by numbering within the array as shown in previous steps. There are different arrays for different data format as shown in the following table:

Registers	Mbus meters data (1...50)	Data format	R/W
	1-st Mbus counter's data		
24000	Status (0-not read, 0xffffread)	Int16	R
24001-24002	Reading time (UNIX time)	Int32	R
24003-24082	Double data[20]	F64	R
24083-24098	Long data[4]	Int64	R
24099-24158	Float data[30]	F32	R
24159-24178	Int data[10]	Int32	R
	2-nd Mbus counter's data		

24179- 24357	...		R
	50-th Mbus counter's data		
32771- 32949	...		R

## 5.10 Communication > Modbus devices

There are two methods for reading Modbus devices connected to the MX-9.

- By using the MODBUS RTU client to request data from MODBUS RTU devices:  
*Communication>Modbus devices>Configuring Modbus devices> Modbus RTU client*

The MX-9 can read up to 50 Modbus RTU devices through each UART. In order to configure Modbus RTU client list, follow the next steps:

- Go to *Communication>Virtual interfaces>Modbus Devices*.
- Once the virtual interface has been enabled under Modbus RTU client- 'UART x' , the list of requests for the Modbus client must be configured. For this purpose go to *Communication>Modbus devices>Configuring modbus devices> Modbus RTU client* .It must be configured as much lines as Modbus RTU requests required. The number of requests can be configured in "Amount of requests", where:
- "Address": Slave device Modbus Address.
- "Function": Modbus RTU function.
- "Registers/coils ":Register/s address to be requested.
- "Amount of registers/coils": number of registers to be read from the register address configured in "Register/coils"
- MX- Reg. index: Internal MX-9's RAM memory index where data is recorded. In case of MX-9 it starts in the address 52000 (index =0 => RAM Modbus address=52000@DEC).
- Priority: It configures the request management priority.

Address	Function	Primary register	Amount of registers	MPC-374 reg. index	Priority	Error priority
1	1	3	0	6	200	0
2	1	3	12	10	206	0
3	1	3	22	2	216	0
4	1	3	70	6	218	0
5	2	3	0	6	224	0
6	2	3	12	10	230	0
7	2	3	22	2	240	0
8	2	3	70	6	242	0
9	6	3	0	3	0	0
10	4	3	0	3	3	0
11	5	3	0	3	6	0

Address	Function	Primary register	Amount of registers	MPC-374 reg. index	Priority	Error priority
1	21	3	17200	16	248	0
2	21	3	17216	16	264	0
3	21	3	17232	2	280	0
4	22	3	17200	16	282	0
5	22	3	17216	16	298	0
6	22	3	17232	2	314	0
7	24	3	17200	16	316	0
8	24	3	17216	16	332	0
9	24	3	17232	2	348	0
10	26	3	17200	16	350	0
11	26	3	17216	16	366	0
12	26	3	17232	2	382	0
13	26	3	17248	16	398	0
14	26	3	17264	16	414	0

**Figure 50. "Modbus devices" tab. Modbus RTU client parameters list configuration**

NOTE: Maximum number of requests per each Modbus RTU Client is 50 NOTE: There exist 2 Modbus RTU clients. In case that both must work together 2 different UARTs must be used, one per each Modbus RTU client.

- By using the Modbus TCP client to collect data from Modbus TCP devices:  
*Communication>Modbus devices>Configuring Modbus devices> Modbus TCP client*

In order to configure Modbus TCP client list, follow the next steps:

- Go to *Communication>Virtual interfaces>Modbus Devices>Configuring Modbus devices> Modbus TCP client*.
- User must configure as much lines as Modbus TCP requests required. The number of requests can be configured in "Amount of requests", where:
- Type: Ethernet/GPRS
- IP: Slave Modbus TCP IP Address
- Port: Slave Modbus TCP port
- "Address": Slave device Modbus Address.
- "Function": Modbus function (3,4,16,...).
- "Registers/coils ": Register/s address to be requested.
- "Amount of registers/coils": number of registers to be read from the register address configured in "Register/coils"
- MX- Reg. index: Internal MX-9's RAM memory index where data is recorded. In case of MX-9 it starts in the address 52000 (index =0 => RAM Modbus address=52000@DEC).
- Priority: It configures the request management priority.

NOTE: In order to remove any request previously set, write '0' in its "Address" column.

The screenshot shows the 'Modbus devices' tab with the 'Modbus TCP/IP client' sub-tab selected. The configuration window includes a 'Value' field, a table for configuring Modbus TCP clients, and 'Set' and 'Get' buttons. Red arrows highlight the 'Modbus TCP/IP client' tab, the 'Value' field, the table, and the 'Set' button.

	Type	IP	Port	Address	Function	Register/Coil	Amount or registers/	MPC reg. index	Priority	Error priority
1	Ethernet	192.168.1.67	1001	254	4	52000	9	100	0	
2	Ethernet	192.168.1.67	1001	1	3	4224	9	200	0	

**Figure 51. "Modbus devices" tab. Modbus TCP client parameters list configuration**

After any of the previous method has been configured, it is possible to check the received information through the Modbus RTU/TCP client in "Current values" tab, also enabling correct performance testing.






Figure 52. “Modbus devices” tab. Current values

## 5.11 Communication > Modbus register grouping

It is also possible to apply data formats or conversions to the MX-9 Modbus registers. For this purpose, go to Communication > Modbus register grouping > Configuration.

In this section, user can configure registers which data need to be converted somehow. Following parameters need to be filled in:

- “Amount of registers”: Number of MX-9 Modbus registers to be converted
- “Multiplier”: Conversion factor to be applied to the Modbus register value
- “Format”: Register data format.

NOTE: Format must be the Input register data format, not the format after conversion.

As an example, if register 52000-52001 corresponds to a pulse counter reading which data format is “int 32”, “integer” option must be selected. Data converted is always stored in “float” format.

Pos	Register	Amount	Value
1	52000	10	0000 012C 0000 0004 0000 0008 0000 0002 0000 0008
2	52010	10	0000 0062 0000 0005 0000 0000 0000 0000 0000 0002
3	52020	10	0000 0008 0000 0004 0000 0000 0000 0000 0000 0002
4	52030	10	0000 0000 0000 0018 0000 0000 0000 0000 0000 0005
5	52040	10	0000 0004 0000 0004 0000 0000 0000 0000 0000 0008
6	52050	10	0000 0003 0000 0005 0000 0000 0000 0000 0000 0003
7	52060	4	0000 0005 0000 0001

Figure 53. Modbus Client Current values (Without conversion)

Register	Multiplier	Format
1	1.2	0.100000 / Float * Integer
2	3.4	100.000000 / Float * Integer
3	5.6	100.000000 / Float * Integer
4	7.8	100.000000 / Float * Integer
5	9.10	100.000000 / Float * Integer
6	11.12	100.000000 / Float * Integer

Figure 54. Configuring Modbus register grouping: Register, Multiplier and data format



Once parameters are properly configured, user will be able to check if conversion is correctly done by visiting *Current values* tab where float-formatted data will be shown in hexadecimal notation.

Pos	Value
1	41F0
2	0000
3	43C8
4	0000
5	4448
6	0000
7	4348
8	0000
9	4416
10	0000
11	4348
12	0000
13	43FA
14	0000
15	0000
16	0000
17	4416
18	0000
19	4348
20	0000
21	4448
22	0000
23	43C8
24	0000
25	447A

Figure 55. Modbus register grouping current values

The Modbus registers converted by the Modbus register group functionality are storage from the **Modbus register: 50875**:

REGISTER	H. BYTE	L. BYTE	INTEGER	FLOAT
50875	41	F0	16880	30.00000
50876	00	00	0	
50877	43	C8	17352	400.00000
50878	00	00	0	
50879	44	48	17480	800.00000
50880	00	00	0	
50881	43	48	17224	200.00000
50882	00	00	0	
50883	44	16	17430	600.00000
50884	00	00	0	
50885	43	48	17224	200.00000
50886	00	00	0	
50887	43	FA	17402	500.00000
50888	00	00	0	
50889	00	00	0	0.00000
50890	00	00	0	
50891	44	16	17430	600.00000
50892	00	00	0	
50893	43	48	17224	200.00000
50894	00	00	0	
50895	44	48	17480	800.00000
50896	00	00	0	
50897	43	C8	17352	400.00000
50898	00	00	0	
50899	44	7A	17530	1000.00000
50900	00	00	0	
50901	44	89	17545	1100.00000
50902	80	00	-32768	

Figure 56. Converted Data from Modbus register grouping

## 6. "Archives" tab

The MX-9 has an internal 8MB flash memory. In case, the device is used as datalogger, the following steps must be done:

- Go to *Archives>Configuration*
- In "Storage parameters" frame, configure the following:
- "*Period*": It defines storage interval. Internal memory is organized in different blocks depending on the devices nature which are connected to the MX-9.




Figure 57. "Archives" tab. Storage frequency configuration

- In case user needs to customize storage blocks, signals acquisition must be configured accordingly. Memory block used will be defined as "User Archive" (see next step).
- Go to *Archives>User Archive Configuration*
- Under this tab, user can configure datalogging following his own requirements. In the next pages, a configuration example is given by setting the following parameters:
- "*Count of parameters*": number of registers to be stored.
- "*Register*": Specific register to be stored. NOTE: Timestamp is registered automatically.





Figure 58. "Archives" tab. User archive configuration

In order to check current data logged in the internal memory, go to *Archives > Values > User archive* tab. This is only a test feature in order to ensure datalogging is performing correctly.



**Figure 59. "Archives" tab. User archive current values**

NOTE: Internal datalogging memory is organized as a file system accessible through the use of standard Modbus function 20 "File register".

## 7. "Limits verification" tab

This tab enables users to set up limits verification raising events for issuing alerts when condition is met. To create the list, follow the next steps:

1. Choose "Count of limits" in order to start creating the number of positions desired;
2. Choose "Type of limit" (this must to be done first) among the following options:
  - i. Over H: event will be generated when the value is above the high limit.
  - ii. Under L: event will be generated when the value is below the low limit.
  - iii. Over H & Under L: event will be generated when the value is out of the range between high and low limit.
  - iv. Under H & Over L: event will be generated when the value is within the range between high and low limit.
  - v. Equal L: event will be generated when the value is equal to the low limit.
3. Enter register number you want to control or choose from Main fields list (To create and/or edit list of limit's values use file limits.csv, that is in program's folder.);
4. Enter data type, corresponding to data type of used register;
5. Choose limits;
6. Delay time (in seconds), if you want to filter accidental or short time events;
7. Finally, add a code of event (value must to be from 0 to 99 and will be used for alerts SMS/email/MQTT message sending)



**Figure 60. "Limits verification" tab**

## 8. "Alerts" tab

MX-9 is able to send short SMS text messages, emails and MQTT messages based on events generated by limits verification feature.

### 8.1 SMS Alerts on Limit verification

SMS alerts for limits is used for sending SMS alerts when alert conditions is set in "Limit verification" tab. Codes of events are used in this screen to configure alert messages as shown in the following figure.

The screenshot displays the 'Alerts' configuration window in the MX-9 software. The 'Limits verification' tab is selected, showing a table of limit events. A green arrow points from the 'Code of event' column in this table to the 'SMS texts for limits' table in the 'Alerts' sub-tab.

Pos No	Main fields	Register	Format	Type of limit	Low limit	High limit	Delay	Code of event
1	Doors closed (on Din 1)	4200	unsigned char	Equal L	0		10	2
2	Doors opened (on Din 1)	4248	unsigned char	Equal L	1		10	1
3	(Ain1) temperature	0	Float	Over H & Under L	0.000	40.000	10	3

The 'Alerts' sub-tab is active, showing the 'SMS texts for limits' table. The 'Event's code' column is highlighted, and a green arrow points from the 'Code of event' column in the 'Limits verification' table to this column.

Event's code	Text of message
0	
1	Doors Opened
2	Doors Closed
3	Temperature out of range (range 0-40)
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	

Figure 61. SMS alerts for limits configuration

### 8.2 Email Alerts on Limit verification

MX-9 can also send email alerts based on codes of events in a similar way it is explained in previous chapter. In order to configure the email sending feature, the following parameters must be set: SMTP server, e-mail address, user name and password. Finally, user can configure up to 5 email accounts to which alerts will be sent.

Events code	Text of message
0	Valor por debajo de 2256
1	Valor por encima de 2230
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	

Figure 62. Email alerts for limits configuration

### 8.3 MQTT Alerts on Limit verification

Finally, MX-9 is able to send JSON formatted messages through MQTT protocol by configuring the following parameters:

- **"Enabled"**: it is recommended to uncheck this box if this feature is not used.
- **"Topic"**: A topic is a UTF-8 string, which is used by the MQTT broker to filter messages for each connected client. A topic consists of one or more topic levels. Each topic level is separated by a forward slash (topic level separator).
- **"Repeat time if failed"**: if message is not properly received by broker, the device will repeat it after seconds configured in this box.

Finally, if configuration is properly done, a message containing the *"text of message"* written in the right column will be inserted into the JSON formatted message according to the event code previously set.

Events code	Text of message
0	Room temperature too high
1	Room temperature below threshold
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	

Figure 63. MQTT alerts for limits configuration

## 9. "Time parameters" tab

This tab enables users to set up time synchronization between MX-9 Real Time Clock (RTC) and external time references. Several parameters can be configured under this tab:

- "Set PC time" It synchronizes internal RTC with PC time.




Figure 64. "Time Parameters" tab. Set PC time

- "Clock synchronization": It must be enabled if synchronization between MX-9 and any Network Time Protocol (NTP) server is requested. This option is particularly accurate since, every given period ("Synchronization period" parameter), device connects to an NTP server to get current UTC time. Also automatic summertime is adjusted.




Figure 65. "Time Parameters" tab. NTP server configuration

## 10. Abbreviations and explanations

- **Xn** – is a number of socket. This information are provided for manufacturer's purpose and used in data schemas and connection diagrams.
- **GSM – Global Standart for Mobile Communications.** This interfaces is prepared for remote connections and data bidirectional data transfer over Global Standart Mobile network.
- **GPRS** - a packet oriented mobile data service on the 2G and 3G cellular communication system's global system for mobile communications (GSM).
- **Ethernet** - a family of computer networking technologies for local area networks (LANs) commercially introduced in 1980. Standardized in IEEE 802.3, Ethernet has largely replaced competing wired LAN technologies. This interfaces is prepared for connection LAN (Local Area Network).
- **IP address** - An **Internet Protocol (IP) address** is a numerical label that is assigned to devices participating in a network that uses the Internet Protocol for communication between its nodes.
- **TCP/IP** – Transmission Control Protocol is for communication between computers, used as a standard for transmitting data over networks and as the basis for standard Internet protocols.
- **MAC address –Media Access Control** address is a unique identifier assigned to most network adapters.
- **UART** – An **Universal Asynchronous Receiver/Transmitter** is a type of “asynchronous receiver/transmitter, a part of computer hardware that translates data between parallel an serial forms. UART are commonly used in conjunction with communication standards such as EIA RS-232, RS-422 or RS-485. Record (UARTx) on top of enclosure also are used as serial interface number.
- **GND** – ground wire contact
- **RS232** - the traditional name for a series of standards for serial binary single-ended data and control signals connecting between a DTE (Data Terminal Equipment) and a DCE (Data Circuit-terminating Equipment). It is commonly used in computer serial ports. The standard defines the electrical characteristics and timing of signals, the meaning of signals, and the physical size and pin out of connectors. RS232 interfaces are prepared for connection of ppheripheral devices (example energy meters, controllers, machines and etc.).
- **TD** – contact for transfer data wire of RS232 socket
- **RD** – contact for read data wire of RS232 socket
- **DTR** – contact for Data Transmit Ready wire of RS232 socket
- **RS485** - standard defining the electrical characteristics of drivers and receivers for use in balanced digital multipoint systems. The standard is published by the ANSI Telecommunications Industry Association/Electronic Industries Alliance (TIA/EIA). Digital communications networks implementing the EIA-485 standard can be used effectively over long distances and in electrically noisy environments. Multiple receivers may be connected to such a network in a linear, multi-drop configuration. RS485 interfaces are prepared for connection of ppheripheral devices (example energy meters, controllers, machines and etc.).
- **A+** – contact for positive wire of RS485 socket
- **B-** –contact for negative wire of RS485 socket
- **USB – Universal Serial Bus** is an industry standard, that defines the cables, connectors and protocols used for connection, communication and power supply between computer and electronic devices. USB type B socket is prepared for connection to PC(Personal Computer). USB type A socket is prepared for connection to ppheripheral devices (example memory stick's and etc.).
- **M-Bus** - a European standard (EN 13757-2 physical and link layer, EN 13757-3 application layer) for the remote reading of gas or electricity meters. The M-Bus interface is made for communication on two wire, making it very cost effective.
- **MBUS+** – contact for M-Bus positive wire



- **MBUS-** – contact for M-Bus negative wire
- **Socket** – is an endpoint of a bidirectional inter-process communication flow across an Internet Protocol-based computer network, such as the Internet.
- **Data** – contact for data wire
- **Req** – contact for request wire
- **CL+** – contact for current loop positive wire
- **CL-** – contact for current loop negative wire
- **Status** – device status indicating LED
- **Uoutput** – status of power for external device indicating LED
- **TX/RX** – data transfer/receive indicating LED
- **TXD** – data transferring LED indicator
- **RXD** – data receiving LED indicator
- **100Mbps** – Ethernet High speed connection indicating LED
- **Central computer** – server or a computer, where data can be sent.

## 12. Safety instructions

To install and setup device, special technical knowledges are needed. Call to seller or certified professionals to connect and setup device!

**Before connecting to power supply, be sure that:**

1. Controller is not damaged (no cracks, melted, broken or exposed areas)
2. Controller is used with right and correct thickness cables.
3. Controller and antenna are installed indoor.
4. The controller is intended for supply from a Limited Power Source (LPS) with current rating of overcurrent protective device not greater than 2A
5. The highest transients on the DC secondary circuit of LPS, derived from AC main supply, shall be less than 71V peak.
6. The associated equipment (AE): PC and PSU (LPS) shall comply with the requirements of Standard EN 60950-1.
7. Controller is dry.
8. Ambient temperature and humidity is in normal range;
9. Other types of devices (counters, etc.) are connected correctly by using manufacturer's regulations.
10. The end of stranded conductor shall not be consolidated by soft soldering and must be terminated
11. Device, PC and other peripheral devices are strictly connected through one double pole breaker (current break less than 5A and space between breaker contacts more than 3mm.) Pole breaker has to be in building's wiring and in reachable place with markings

**Don't use:**

1. Device under open water (in rain and if water are splashing on controller or connected devices;
2. Device if enclosure, connected cables, or other connected devices are damaged;
3. External Back-Up batteries for powering of controller.



**Use device by manufacturer's regulations otherwise** you can damage controller or other devices. In that case **manufacturer's warranty could not be obtained.**



**If you suspect that device doesn't operate correctly** or has visible violations, please contact manufacturer or your distributor to check or run maintenance.



**Manufacturer** does not affect and is not responsible for GSM/GPRS/Internet operators' provided network service pricing and costs.

## 13. Technical Data

### 13.1 Communication interfaces

Interfaces	Technical data
RS485	Up to 1.2 km, max 32 transceivers, speed up to 57600 bps
RS232	Up to 15m, speed up to 57600 bps
M-Bus	Up to 8 devices
Wireless M-Bus	Up to 50 devices
GPRS	Transmission frequency bands: Quad-band 850, 900, 1800, 1900 Transmission Power: Class 4 (2W) at GSM850 and EGSM 900 Class 1 (1W) at DCS1800 and PCS1900 Receiver sensitivity (typical) -109dBm, (Max) -107dBm Modulation type: GSMK
Ethernet	10/100 Mb twisted pair, up to 100m
USB	Type B, version 2.0

### 13.2 Galvanic insulation

Insulation voltage between power supply and second circuits	1500 V
Insulated interfaces	B, C

### 13.3 Indication

Indication type	LED's
Indicated parameters	<ul style="list-style-type: none"> <li>Status of each Serial interface</li> <li>• GSM/GPRS modem status</li> <li>• GSM/GPRS modem transfer and receive</li> <li>• Ethernet Duplex mode status</li> <li>• Ethernet High speed connection status</li> <li>• Ethernet Transfer/Receive status</li> </ul>

### 13.4 Power supply

Power supply	9 ÷ 36 V $\overline{\text{---}}$ / 12 ÷ 50 V $\overline{\text{---}}$
Power consumption	300mA max

### 13.5 Construction

Mounting	DIN rail
Dimensions	147 mm x 128 mm x 50 mm
Tightness	IP20

### 13.6 Climate conditions

Operating temperature	From - 25 °C to + 60°C
Storage temperature	From - 40 °C to + 60°C
Relative humidity	From 5 % to 95 % non-condensing

### 13.7 Safety parameters

Safety requirements	Meets requirements: LST EN 60950-1:2006 LST EN 60950-1:2006/A11:2009
Electromagnetic compatibility	Meets requirements: EN 55022:2000+A1+AC:2002+A2:2003 EN 55024:2000+A1:2003+A2:2003 EN 61000-4-5:2002+A1:2003 EN 61000-4-6:2002+A1:2003 EN 61000-4-2+A1+A2:2002 EN 61000-4-3+A1:2004 EN 61000-4-4:2005

### 13.8 Other parameters

Storage memory	8 MB
Remote firmware loading	Yes. Through USB or/and Ethernet and GSM/GPRS.